



NOTES:

1. DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR SHOTCRETE APPLICATIONS USING HENRY **BLUESKIN PRESEAL 435**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
2. INSTALL SHOTCRETE IN ACCORDANCE WITH ACI 506.2-13, SPECIFICATION FOR SHOTCRETE INCLUDING, BUT NOT LIMITED TO, MINIMIZING LIFT HEIGHT (TRADITIONALLY 4'-0"), OVERSPRAY, AND EXCESSIVE REBOUND AT LIFT AREA.
3. TAPE **BLUESKIN PRESEAL 435** SEAMS WITH **BLUESKIN PRESEAL TAPE 120V**.
4. HENRY RECOMMENDS THE USE OF A DRAINBOARD IN NON-HYDROSTATIC CONDITIONS, OR AS A SUBSTRATE PREPARATION.
5. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY PRE-APPLIED WATERPROOFING SYSTEM

SLAB TO WALL TRANSITION
BLUESKIN PRESEAL 435 - SHOTCRETE APPLICATIONS
INSTALLED OVER LAGGING

SCALE: N.T.S.

11-06-2023

BSPS-1A.1S

Henry
 A CARLISLE COMPANY