

NOTES:

- 1. DETAIL SHOWS **HENRY 790-11/790-11EV** HOT RUBBERIZED ASPHALT WATERPROOFING ASSEMBLY TRANSITION WITH HENRY **PUMADEQ SYSTEM**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- RECOMMENDED HENRY ADHESIVE/PRIMER FOR HENRY 790-11/790-11EV INCLUDE: HENRY 910-01 ASPHALT PRIMER
 OR HENRY 930-18 POLYMER MODIFIED ADHESIVE. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET TO
 CONFIRM VOC COMPLIANCE.
- TRANSITION DETAIL IS SUITABLE FOR BOTH REINFORCED AND UNREINFORCED PUMADEQ SYSTEM FIELD
 MEMBRANE APPLICATIONS. TOP, WEAR, AND TRAFFIC COATING NOT SHOWN FOR CLARITY. REFER TO PUMADEQ
 SYSTEM DETAILS FOR FURTHER CLARITY.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY **PUMADEQ** SYSTEM SUBSTRATE PREPARATION GUIDELINES.
- HENRY OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS. CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 6. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR

HENRY 790-11/790-11EV AND PUMADEQ SYSTEM TIE IN

TIE-IN DETAIL

DISSIMILAR MATERIAL TRANSITIONS HENRY 790-11/790-11EV AND PUMADEQ SYSTEM SCALE: N.T.S. 0

07-08-2019

790-11-TID-3A2

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com