



Notes:

1. The Blueskin membrane extending over the parapet exterior is for waterproofing only.
2. Blueskin is self-sealing when self-taping fastening systems are used.
3. Air barriers should be continuously supported throughout the building envelope. Use galvanized sheet metal, exterior sheathing or other method to provide support around the perimeter of steel deck assemblies.
4. Air-Bloc 21 can also be used as an adhesive to bond rigid insulation to CMU or other substrates, including Air-Bloc and Blueskin.

Henry
COMPANY

AIR-BLOC 06, 21 OR 32

SCALE: N.T.S.

BRICK VENEER/ CMU WALL

FIT TO PAPER

**PARAPET
DETAIL**

AB-H102