



Notes:

1. Blueskin TWF is a self-adhering sheet used for thru-wall flashing applications. Blueskin TWF is to be applied to a prepared and primed substrate.
2. Always stop Blueskin TWF flashing membrane back from exterior face of veneer. Extend the drip edge using prepainted metal to suit.
3. Air-Bloc 21 may be used as an adhesive to bond rigid insulation to exterior sheathing or other Air-Bloc systems. Air-Bloc 21 is applied by notched trowel or gunned in a serpentine pattern to the back of the insulation panels to restrict air movement. Insulation panel joints are also buttered.

Henry
COMPANY

AIR-BLOC 06, 21 OR 32

SCALE: N.T.S.

BRICK VENEER/ CMU WALL

FIT TO PAPER

**SHELF ANGLE
DETAIL**

AB-H106