



1. Deck
2. Aquatac Primer or Blueskin Adhesive
3. Blueskin WP 200 Membrane
4. HE925 or Polybitume
5. HE925 or Polybitume
6. Synko-Flex or Hydro-Flex Waterstop
7. Henry recommends the use of insulation or a drainage composite as a protection layer over Blueskin WP200 (not shown for clarity).

Notes:

1. System detail showing typical application to a concrete foundation wall and deck.
2. Blueskin WP 200 must be protected. Use extruded polystyrene insulated assemblies. Prefabricated geocomposite drainage boards, polypropylene, or asphaltic protection board may also be used.



BLUESKIN WP-200

SCALE: N.T.S.

FOUNDATION WALL APPLICATIONS

SYSTEM
DETAIL

ES-H101