



## Notes

1. Joint surfaces should be clean and dry before priming and prior to placing the Synko-Flex®, Synko-Flex® FR or Hydro-Flex® strips.
2. Prime using SF311 - SYNKO-FLEX® Solvent Based Primer or SF300 – Synko-Flex® Emulsion Primer. Refer to product technical data sheet for more information.
3. Concrete should cure a minimum of 24 hours prior to priming.
4. Concrete keyway is not required for the use of this product.
5. Minimum of two inches of concrete coverage is recommended.
6. Splice the end of each strip to the next strip with a 25mm (1") overlap.

Synko-Flex® & Hydro-Flex® Waterstop

## DECK TO WALL DETAIL

PREFORMED ADHESIVE  
WATERSTOP

Scale: N.T.S.

Author: CA

Issued: 01-11-16

Revision: 01

# SF-2B16

# Henry®

15 Walsend Drive, Toronto ON M1E 3X6  
 Technical Services - 800-486-1278  
 Email: techservices@henry.com  
 www.ca.henry.com