



Notes

1. Joint surfaces should be clean and dry before priming and prior to placing the Synko-Flex®, Synko-Flex® FR or Hydro-Flex® strips.
2. Prime using SF311 - SYNKO-FLEX® Solvent Based Primer or SF300 – Synko-Flex® Emulsion Primer. Refer to product technical data sheet for more information.
3. Wrap Synko-Flex®, Synko-Flex® or Hydro-Flex® strip around projection onto the primed surface pressing firmly along the entire length of the strip.
4. Where necessary, splice the end of each strip to the next strip with a 25mm (1") overlap.

Synko-Flex® & Hydro-Flex® Waterstop

**PROJECTION
DETAIL**

PREFORMED ADHESIVE
WATERSTOP

Scale: N.T.S.

Author: CA

Issued: 01-11-16

Revision: 01

SF-3B16

Henry®

15 Walsend Drive, Toronto ON M1E 3X6
 Technical Services - 800-486-1278
 Email: techservices@henry.com
 www.ca.henry.com