



Notes

1. Drain designs vary. Always refer to drain manufacturer's recommendations.
2. The base sheet flashing and the cap sheet should be mechanically clamped by the drain assembly.
3. Position the target sheet 45 degrees to the base sheet. Use a full sheet cut square.

modifiedPLUS Roofing Systems

ROOF DRAIN

P.M.R. ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

MB-16E97



Henry Company
 2911 Slauson Avenue, Huntington Park CA 90255
 (800) 486-1278 techservices@henry.com
<http://www.henry.com>