



Metal Cap Flashing  
 modifiedPLUS SA Cap Flashing  
 modifiedPLUS BlueBase Flashing  
 Aquatac Primer  
 Substrate

modifiedPLUS SA Cap Flashing  
 modifiedPLUS SA Cap Sheet  
 modifiedPLUS BlueBase Flashing  
 modifiedPLUS BlueBase Sheet  
 Re-Cover Board  
 Wood Cant Strip  
 Tapered Insulation (Optional)  
 Primary Insulation  
 Air/Vapor Barrier  
 Sheathing (Optional)  
 Deck

2" min.

8" min.

**Notes**

1. modifiedPLUS SA is a self-adhered roofing membrane system.
2. The Re-Cover Board overlay is mandatory on all insulated applications.
3. Wood cant strips are required when installing modifiedPLUS SA roofing membrane systems. Priming is required for all substrates, except to Re-Cover Board.
4. An air/vapor barrier transition membrane such as Bliveskin is installed prior to building the wood parapet. This ties the roofing system into the air/vapor barrier to maintain continuity.

modifiedPLUS SA Roofing Systems

**PARAPET DETAIL**

SELF-ADHERED ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 09-01-00

Revision: 02

**MB-19E00**



**Henry Company**  
 2911 Slauson Avenue, Huntington Park CA 90255  
 (800) 486-1278 techservices@henry.com  
<http://www.henry.com>