



### Notes

1. The reglet should be a minimum of 8" from the finished roof surface.
2. Ensure reglet is blown clean prior to applying sealant.
3. The modifiedPLUS membranes may be thermofused, self-adhered, applied in hot asphalt, or applied in cold adhesive. Consult Technical Data Sheets for specific information as well as priming requirements.

modifiedPLUS Roofing Systems

## REGLET COUNTERFLASHING

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

# MB-3E97

# Henry

Henry Company  
2911 Slauson Avenue, Huntington Park CA 90255  
(800) 486-1278 techservices@henry.com  
<http://www.henry.com>