



## Notes

1. Fasten the metal flashing to the wood blocking in a staggered pattern. Frequent fastening will reduce thermal movement.
2. Ensure deck slopes to drain, scupper or eavestrough on perimeter.
3. Priming is required for all thermofused applications, except to Re-Cover Board or "torch safe" insulation products, use 930-18 or 910-01. For self-adhered membranes, use 930-38 or 900-34 primer.

modifiedPLUS Roofing Systems

## ROOF EDGE

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

# MB-5E97

# Henry

Henry Company  
2911 Slauson Avenue, Huntington Park CA 90255  
(800) 486-1278 techservices@henry.com  
<http://www.henry.com>