



### Notes

1. Fasten cant strip solidly to wood blocking using mechanical fasteners.
2. Extend the base flashing sheet down the outside face beyond wood blocking and fasten at 8" o.c.

modifiedPLUS Roofing Systems

## CANTED ROOF EDGE

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

# MB-6E97



**Henry Company**  
2911 Slauson Avenue, Huntington Park CA 90255  
(800) 486-1278 techservices@henry.com  
<http://www.henry.com>