



Notes

1. The membranes should be mechanically clamped by the drain assembly.
2. A minimum slope of 1:50 (1/4":12') to drain is recommended.
3. Drainage in the immediate area around the drain may be facilitated by tapering the insulation and incorporating a sump.
4. Position target sheet 45 degrees to the base sheet. Use a full width sheet cut square, 39" x 39".
5. Drain designs vary. Always refer to drain manufacturer's recommendations.

modifiedPLUS Roofing Systems

ROOF DRAIN

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 05-14-97

Revision: 04

MB-8E97



Henry Company
 2911 Slauson Avenue, Huntington Park CA 90255
 (800) 486-1278 techservices@henry.com
<http://www.henry.com>