

HENRY AIR BARRIER
(CONTACT HENRY FOR PROJECT
SPECIFIC RECOMMENDATIONS)


HENRY 925 BES SEALANT

BLUESKIN WP200
(PRIMER NOT SHOWN FOR
CLARITY - SEE DATA SHEET
FOR RECOMMENDATIONS)

BLUESKIN PRESEAL 320
OR BLUESKIN PRESEAL 435
(SEE NOTE #2)

HENRY DRAINBOARD
(SEE NOTE #3)

CLADDING NOT SHOWN FOR CLARITY
(PROTECT HENRY AIR BARRIER AND
BLUESKIN WP200 FROM INDEFINITE
UV EXPOSURE)



NOTES:

1. DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR APPLICATIONS USING HENRY **BLUESKIN PRESEAL 320** OR **BLUESKIN PRESEAL 435**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
2. HENRY **BLUESKIN PRESEAL 435** CAN BE INSTALLED DIRECTLY ONTO SHEET PILING. **BLUESKIN PRESEAL 320** REQUIRES A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD.
3. HENRY RECOMMENDS THE USE OF A DRAINBOARD IN NON-HYDROSTATIC CONDITIONS, OR AS A SUBSTRATE PREPARATION.
4. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET (TDS) AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY PRE-APPLIED WATERPROOFING SYSTEM

POST-APPLIED TRANSITION
BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435
TRANSITION WITH BLUESKIN WP200 - AT GRADE

SCALE: N.T.S. 09-14-2022

BSPS-10B4