

HENRY FILTER FABRIC

HENRY DRAINBOARD
(SEE NOTE #4)

BLUESKIN WP200
(PRIMER NOT SHOWN FOR
CLARITY - SEE DATA SHEET
FOR RECOMMENDATIONS)

MODIFIEDPLUS G100S/S

HENRY 790-11/790-11EV 2-PLY
215 MIL REINFORCED WITH
POLYESTER FABRIC

HENRY 910-01 ASPHALT
PRIMER OR
HENRY 930-18 POLYMER
MODIFIED ADHESIVE

SYNKO-FLEX WATERSTOP,
MIRASTOP BW, OR MIRASTOP NBW
(SEE NOTE #3)

BLUESKIN PRESEAL 320
OR BLUESKIN PRESEAL 435
(SEE NOTE #2)

SOIL RETENTION SYSTEM
(DO NOT INSTALL **BLUESKIN
PRESEAL 320** DIRECTLY ONTO SHEET
PILING - PREPARE SUBSTRATE WITH
A SMOOTH SURFACE SUCH AS
PLYWOOD OR DRAINBOARD)

4" (100MM)

4" (100MM)

6" (150MM)

EXTEND
PRE-APPLIED
WATERPROOFING
TO ANTICIPATED
CONCRETE
LEDGE AND
TEMPORARILY
SECURE UNTIL
SUBSTRATE IS IN
ACCORDANCE
WITH
INSTALLATION
REQUIREMENTS

NOTES:

1. DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR APPLICATIONS USING HENRY **BLUESKIN PRESEAL 320** OR **BLUESKIN PRESEAL 435**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
2. HENRY **BLUESKIN PRESEAL 435** CAN BE INSTALLED DIRECTLY ONTO SHEET PILING. **BLUESKIN PRESEAL 320** REQUIRES A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD.
3. APPLICATIONS USING SWELLABLE WATERSTOPS: 3" (75MM) MINIMUM CONCRETE COVERAGE ON ALL SIDES.
4. HENRY RECOMMENDS THE USE OF A DRAINBOARD IN NON-HYDROSTATIC CONDITIONS, OR AS A SUBSTRATE PREPARATION.
5. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET (TDS) AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY PRE-APPLIED WATERPROOFING SYSTEM

DECK TO WALL TRANSITION
BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435
TRANSITION WITH HENRY 790-11/HENRY 790-11EV

SCALE: N.T.S.

09-14-2022

BSPS-7A2