



PUMADEQ PRIMER 20
OR HENRY GC PRIMER

PUMADEQ FLEX 31MV REINFORCED
WITH PUMADEQ N-FLEECE

8" SUGGESTED

6"

PROTECTION COURSE OPTIONS

- MODIFIEDPLUS G100S/S
- PROTECTION FABRIC - GR08
- HENRY CM100 (60 MILS)
- POLYESTER FABRIC
- HENRY CM100 (60 MILS)

NOTES:

1. DETAIL SHOWS **HENRY CM100** REINFORCED COLD FLUID-APPLIED WATERPROOFING ASSEMBLY TRANSITION WITH HENRY **PUMADEQ SYSTEM** FLASHING. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ SYSTEM** APPLICATION IN ACCORDANCE WITH HENRY **PUMADEQ SYSTEM** SUBSTRATE PREPARATION GUIDELINES.
3. BACK COAT FLEECE ON VERTICAL SUBSTRATE WITH **PUMADEQ FLEX 31MV**.
4. HENRY OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS. CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
5. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry[®]

999 N. Pacific Coast Highway, Suite 800
El Segundo, CA 90245
800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY CM100 AND PUMADEQ SYSTEM TIE IN

CURB FLASHING

**CORNER FLASHING AT UPTURN
HENRY CM100 AND PUMADEQ SYSTEM**

SCALE: N.T.S.

07-08-2019

CM100-TID-3C2