


PUMADEQ GRIP 40
PUMADEQ FLEX 31MV REINFORCED WITH PUMADEQ N-FLEECE
PUMADEQ PRIMER 20

OPTIONAL WEAR COAT

- **HENRY GP WEARCOAT (26 MILS)**
- **DRY SILICA SAND (SEE NOTE #3)**
- HENRY PRODEQ FX 400 (100 MILS)**
- PRODEQ SYSTEM PRIMER (SEE NOTE #2)**



PROTECTION COURSE OPTIONS

- **MODIFIEDPLUS G100S/S**
- **PROTECTION FABRIC - GR08**
- HENRY CM100 (60 MILS)**
- POLYESTER FABRIC**
- HENRY CM100 (60 MILS)**

NOTES:

1. DETAIL SHOWS **HENRY CM100** REINFORCED COLD FLUID-APPLIED WATERPROOFING ASSEMBLY TRANSITION WITH HENRY **PRODEQ SYSTEM**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. THE STANDARD PRIMER FOR THE HENRY **PRODEQ SYSTEM** IS **HENRY ST PRIMER** WITH AGGREGATE. OTHER RECOMMENDED PRIMERS INCLUDE: **HENRY LV PRIMER**, **HENRY STXL PRIMER** WITH AGGREGATE, **PUMADEQ PRIMER 20** WITH AGGREGATE AND **HENRY GC EPOXY PRIMER**. REFER TO PRODUCT SPECIFIC DATA SHEET FOR PRODUCT SPECIFIC INFORMATION.
3. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ SYSTEM** APPLICATION IN ACCORDANCE WITH HENRY **PUMADEQ SYSTEM** SUBSTRATE PREPARATION GUIDELINES.
4. DO NOT INSTALL **PRODEQ SYSTEM** BEYOND PRIMED SURFACES.
5. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



999 N. Pacific Coast Highway, Suite 800
 El Segundo, CA 90245
 800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY CM100 AND PUMADEQ SYSTEM TIE IN

TIE-IN DETAIL

DISSIMILAR MATERIAL TRANSITION
HENRY CM100 AND PRODEQ SYSTEM

SCALE: N.T.S. 03-01-2022

CM100-TID-4A1